




1. The IP address of your camera is http:// 60.248.39.146:1025
2. Please select the “Custom” in the Transport Setup.



3. Select HTTP protocol and "Port ID" as custom



4. Set the Custom port ID as 1025 and click OK.



5. Open URL and input URL “rtsp://60.248.39.146/live.sdp